

GREAT BAY SPA & SAUNA
275 Constitution Ave.
Portsmouth, NH 03801
800-436-8893

WINTERIZING SPAS INDOORS VS. OUTDOORS

A) OUTSIDE SPAS

We drain the spa. Suck out all the lines with a shop vac. Turn on the blower (if applicable) to get all the water out of those lines. Support the cover if necessary. Install a poly plastic sheet and plastic tarp on top of spa. Use string to tie down the cover. If spa is sunk into a deck, string might be screwed into the joists. A plywood cover may be necessary.

B) INSIDE SPAS

We drain the spa and suck out all the lines with a shop vac. Turn on the blower (if applicable) to get all the water out of those lines. No other work is necessary.

*Customer needs to supply outlet and power disconnect. If they are not provided and we have to go back, customer will be charged.